



ON-TRACK PLANT

ENGINEERING CONFORMANCE CERTIFICATE

This certificate issued in accordance with RIS-1530-PLT Issue 6.

NAME OF CERTIFICATION BODY

ACCREDITATION CODE

AEGIS Certification Services Ltd

AC

Machine Class/Description	Rexauote Case	e CX135 Crawleraile	er (Type 9A)
---------------------------	---------------	---------------------	--------------

Vehicle Owner William Bradshaw Plant Hire

Issue Date 9th Aug 2019

Expiry Date 9th Aug 2026

Vehicle Number: 99709 911253-1

First of Class Yes

Certificate Number of First of Class AC/0134/19

Authorised by:

Official Stamp



L D'Angelo AEGIS PAB Signatory

Reason for Issue and Scope of Work

Previous Certificate:
Upgrade to RIS-1530-PLT, Issue 3.
GOS Operator & Maintenance Manual Addendum RP142, Issue 1.
New Limitations of Use 6 and 14.
Change of Owner.

Plant Asset Manager Copy

Certificate Number: AC/0134/19

Page 1 of 4





This certificate:

Upgrade to RIS-1530-PLT issue 6 specification. Fit Ris-1530-PLT issue 6 compliant GKD Spaceguard system

Maximum on/off tracking increased to 150mm of Cant

Fit 50mm² earth bonds.

Change of Owners name

Deviations Associated with this Certificate

Reference None **Title** None

Previous Certificate Number: IF/0177/14

Approved Maintenance Instructions

 ID No.
 Title
 Issue No.
 Date

 AJH 142
 Case
 CX135
 MONO
 & Z-Boom
 1
 29/07/2019

Configurations Operation and Maintenance

Instruction

Machine Data

Gross Mass	19500 kg	Gauge	W6a
Front end equipment gauge exceedance	5410 mm		
Tailswing gauge exceedance	203 mm	Tailswing Height	1192 mm
Software version (inc. RCI)	9.39	-	-

Approved Values

Maximum number of people	1		
Main load lifting point SWL	10000 kg	Auxiliary lifting point SWL	5 000 kg

Approved Track Conditions

	Travelling Mode	Working Mode	On/off-tracking
Maximum gradient	1:25	1:25	1:25
Maximum cant	200 mm	150 mm	150 mm
Minimum curve radius	80 m	80 m	

Plant Asset Manager Copy

Page 2 of 4

Certificate Number: AC/0134/19





Approved Maximum Speeds

	Travelling Mode	Working Mode
Plain Line	15 mph	10 mph
Switches and Crossings	5 mph	5 mph
Raised check and guard rails	5 mph	5 mph
Reverse	5 mph	5 mph
Emergency recovery	3 mph	3mph

Limitations of Use

- 1. The machine shall not be used outside a possession.
- 2. The maximum number of people transported on this machine shall not exceed the value given in the Approved Values section of this ECC.
- 3. Lifts shall not exceed any SWL given in the Approved Values section of this ECC.
- 4. The machine shall not be used on track conditions in excess of those given in the Approved Track Conditions section of this ECC.
- 5. The machine speed shall not exceed the values given in the Approved Maximum Speeds section of this ECC.
- 6. The machine exceeds Plant Gauge, see Machine Data section of this ECC.
- 7. When travelling, mirrors must be folded in.
- 8. The machine exceeds the stated gauge in working mode, see Machine Data section of this ECC. The machine may be used with adjacent lines open to traffic only if a safe system of work to be adopted has taken account of gauge exceedance.
- 9. If adjacent lines are open to traffic, this machine shall be used only if a safe system of work has been adopted to take account of the extra gauge exceedance caused by attachments.
- 10. The machine is to proceed at walking speed and ground staff control the movement in reverse until the superstructure can be slewed to face direction of travel.
- 11. The machine may only operate with the access adjacent to a cess or a line closed to all train movements or the documented safe system of work must take account of adequate safe clearances to adjacent lines.
- 12. Not to be used ALO on LU.
- 13. This machine is suitable for on/off-tracking, traveling and working under the live OLE when used in conjunction with a safe system of work.
- 14. Except for the cab, access is not permitted to any surface greater than 1.4 m above rail level under live OLE.
- 15. The machine shall not be used in live conductor rail areas.





- 16. Where an attachment is known to have a significant adverse effect on stability the RCI shall always be in "Lift Mode" when using the attachment.
- 17. The machine shall not be used predominantly in enclosed locations.
- 18. Machine is not permitted to tow or propel trailers.

Supplementary Information

- 1. This machine's re-approval for seven years was assessed against RIS-1530-PLT issue 6.
- 2. Duty chart reference (bucket pin, Auxiliary Lifting Point and Quick Hitch): Case CX135 Serial No 0372 26-Jul-2019
- 3. The machine is approved for use with a Geith Quick Hitch fitted to the dipper end.
- 4. A High Performance Movement Limiting Device controlled through the GKD is fitted.

Serial Number	0372
Plant Number	49

Authorised by:	

L D'Angelo AEGIS PAB Signatory

Certificate Number: AC/0134/19